
CARE INSTRUCTIONS

A well cared for fingerboard will last for years to come. Do not stack anything on top of your fingerboard. Store it indoors in a **cool dry area** and keep it **away from direct sunlight**, humidity, moisture, or liquids.

- ALWAYS DUST OFF YOUR FINGERBOARD BEFORE PLAYING. Sand/dust/pet hair on the surface of the board may slow the discs down or even cause scratches on the surface of the board.
- Do not use furniture cleaner or other cleaning sprays on the surface of your fingerboard.
- You should not have to do any treatment to the surface (except wipe it down). If the surface gets scratches over time and you desire a smoother surface, we recommend a ***thin even*** coat of **Carnauba Wax**, also known as the "queen of waxes". We use the brand *The Real Milk Paint Co.* Use a piece of soft cloth (like an old t-shirt), fold it in a small square (you want a flat surface with no wrinkles) to apply the wax. Let it dry and rub it off with a soft piece of cloth. Carnauba wax is also perfect to use on the fingerboard frame and other furniture. Another option is *Minwax® Paste Finishing Wax (Natural)*, but Carnauba Wax is superior and easier to apply. Avoid getting wax on the rubber strips.
- We do not recommend using baby powder or corn starch on the surface. If any disc does not glide smoothly please contact us.

